


























Product Manuals / Návod k výrobku / Návod k výrobku

					 A × 2PCS		 B × 2PCS		 C × 1PC	
					 E × 1PC		 F × 4PCS		 D × 2PCS	 G × 2PCS
					 K × 1PC	 Q × 1PC	 H × 1PC			
 M × 2PCS	 U × 2PCS	 S × 18PCS	 T × 18PCS	 N × 22PCS	 I × 2PCS		 J × 2PCS			
 X × 2PCS	 O × 4PCS	 L × 4PCS	 P × 4PCS	 R × 4PCS	 V × 1PC	 W × 1PC				

General Care:

*For clearing, wipe the surface with a damp (not wet) cloth or sponge or wipe dry with a clean lint free cotton cloth.

Pokyny k ošetrovaniu:


*K čišteniu používajte vlhký hadřík nebo houbu, nebo ho otřete suchým nechlupatým bavlněným hadříkem.

Pokyny k ošetrovaniu:


*Na čistenie používajte vlhkú handričku alebo špongiu, alebo ho utrite suchou nechľapatou bavlnenou handričkou.




1



2



3



4

